

GLASS WASH 1

ALKALINE DETERGENT CLEANER

CONCENTRATED ALKALINE DETERGENT CLEANER

Heavy duty Alkali detergent, non foaming and ideal for use in all types of glass washers for the removal of soiling and staining commonly associated with glassware and associated equipment. Glass wash 1 is recommended for use on Glass, plastic and stainless steel items.

Glass Wash 1 is economical, versatile and has multi-surface use, suitable on both hard and soft water applications. Glass Wash 1 effectively cleans and is low foaming, it is phosphate & solvent free and it is fully bio-degradable.

Works in all makes and models of glass washers & washer dryers.

Application

1. Place feed tube into bottom of container and check automatic feed equipment is switched on.
2. Inject at 4ml per 1 litre of water at a working temperature of 45 – 60 °C.

Material Compatibility

Glass Wash 1 is compatible with the following materials: Stainless Steel, Aluminium, Anodised aluminium, Chromium plated material, Synthetic materials, Rubber, Latex, Glass, Ceramics, Copper, Brass, Metal alloys.

Warnings and Cautions

- Do not add any other chemicals, such as bleach or detergents. Added chemicals may destroy the effectiveness of this product.
- Wear goggles, plastic apron, rubber gloves, when changing containers.
- Consult the manufacturers recommended reprocessing instructions to determine cleaning agent compatibility and any additional procedures necessary to clean their particular medical device.
- Store in a cool place between 5 and 25°C.
- Dispose in accordance with local authority guidelines.



Available in 5L and 10L.